

Bluetooth Scanner

Quick Start Guide

- ▶ Outdoor 50 m viewing distance wireless transmission
- ▶ With a variety of PC Bluetooth a key match
- ▶ Built-in FLASH memory support for HTTP
- ▶ Offline scanning barcodes can store more than 5000
- ▶ Supports normal mode, counting mode, the mode is not lost, SPP mode and can switch freely
- ▶ Support for Windows XP, Win 7 Win8 / 10 system PC. Android devices, IOS devices
- ▶ Supports the HID protocol, SPP agreement



4 And Android, ios Match system

1. Start Bluetooth scanner, press the Bluetooth button on the scanner or sweep 8 seconds pairing bar code will go into pairing mode [], the connection indicator (blue) flashes rapidly
2. Open the Bluetooth device to search General Bluetooth HID Barcode
3. Click on the Bluetooth device, pairing status
4. The pairing is successful, the Bluetooth indicator light blue lights lit scanner.

1 And Windows XP Match system

1. Insert the Bluetooth scanner receivers, the computer will automatically install the Bluetooth receiver to drive (the installation process can not pull out the receiver)
2. Start the Bluetooth scanner, press the Bluetooth scanner 8 seconds or sweep pairing bar code will go into pairing mode [], the connection indicator (blue) flashes rapidly
3. Locate the Bluetooth Computer Control Panel, open the Bluetooth panel, click the Add button
4. Select "My device is set up and ready, you can find", click Next
5. The Add Bluetooth Device Wizard dialog box should appear a General Bluetooth HID Barcode device icon
6. Double-click General Bluetooth HID Barcode equipment icon key dialog box appears, choose not to use keys, the next step will begin installing the driver
7. After a successful installation of the Bluetooth device in more than a General Bluetooth HID Barcode equipment, while Bluetooth scanners short beep sound, this Bluetooth adapter installed
8. pairing is successful, the Bluetooth indicator light blue lights lit scanner

2 And Windows7 Match system

1. Insert the Bluetooth scanner receivers, the computer will automatically install the Bluetooth receiver to drive (the installation process can not pull out the receiver)
2. Start the Bluetooth scanner, press the Bluetooth button on the scanner or sweep 8 seconds pairing bar code will go into pairing mode [], the connection indicator (blue) flashes rapidly
3. Locate the "Devices and Printers" in the computer control panel, click on the "Add Device"
4. The Add Bluetooth Device Wizard dialog box should appear a General Bluetooth HID Barcode device icon
5. Right-click "General Bluetooth HID Barcode" device icon "Properties" option, the Properties dialog box appears, click OK. At this point the computer prompts the driver is being installed
6. Wait for the computer to install the driver is complete, the scanner Bluetooth indicator (blue) If the indicator is a Bluetooth scanner and computer connection is successful

3 And Windows 8 / Windows 10 Match system

1. Insert the Bluetooth scanner receivers, the computer will automatically install the Bluetooth receiver to drive (the installation process can not pull out the receiver)
2. Start the Bluetooth scanner, press the Bluetooth button on the scanner or sweep 8 seconds pairing bar code will go into pairing mode [], the connection indicator (blue) flashes rapidly
3. Open the Control Panel, click on the "Add Device", the computer will search to General Bluetooth HID Barcode equipment
4. Double-click the device or click on Next, the computer will automatically install the driver
5. The driver is installed, Bluetooth scanner indicator (blue) If the bar code gun or a short beep sound, indicating that the Bluetooth scanner has been successfully connected to the computer

Barcode mode feature set



Links pairing mode



No loss pattern



Serial mode



SPP mode



HID (USB) mode



Count mode



Normal mode



The total number of data



Data Upload



clear data



IOS show hidden keyboard



IOS keyboard keys, double-click Show hidden



Barcode tone sweep to open



Barcode sweep tone Close



Barcode Upload tone open




Barcode Upload tone Close



Shutdown Mode



Hardware version information



Bluetooth restore factory settings



Software version information



Warning!

Barcode above Use with caution

Sleep Time Setting



Start setting



5 of 5 stars



30 seconds



60 seconds



2 minutes



10 points



20 points



No scanner sleep mode

Language selection (default American English)



American English



French



German



Italian language



Russian

Buzzer

Buzzer mode and description

Blew two seconds:

Bluetooth module initialization error, external EEPROM full

3 sounding voice:

Low battery, the battery voltage is lower than 3.2V

Short beeps 20 times:

External memory initialization error, external EEPROM read and write errors

Short beeps 1:

Upload Start upload OK, set the Start, Settings OK

Short beeps twice:

Power-OK, RF transmission OK (gun Bluetooth connection is successful)

Short beeps 3 times:

Bluetooth error (Bluetooth connection failed gun)

Short beeps five times:

Setting error, matching error

LED lights

LED color and description

Green light and quickly extinguished:

Successfully read the bar code, also issued short beeps

Two blue lights flashing together:

Enter the pattern, waiting for a terminal connected to the device

A blue light flashes:

Enter the pattern, waiting for a terminal connected to the device

A steady blue light:

Successful match and connect the device, while short beeps twice

Red light:

State of charge

Flashing red:

Battery connection is bad

common problem

► Bluetooth scanners and Android phones can not connect how to do?

Check that your phone is android 3.0 or more can be directly connected

► Why are not part of the bar code scanner?

Because some not commonly used bar code at the factory default setting is off, you can simply open the corresponding bar code settings can be a normal scan, if you do not know the appropriate type of bar code, please contact the manufacturer

► Why after pairing bar code can not be uploaded to a computer or cell phone?

1. Verify whether the pairing is successful, the pairing is successful Bluetooth Scanner LED display is blue
2. You have opened the inventory functions (inventory under the bar code does not automatically upload mode, you need to manually sweep the corresponding bar code upload)
3. Change to the normal mode, you can upload one side while scanning

► Computer or mobile phone search is not a Bluetooth scanner how to do?

1. Make sure the scanner is turned on Bluetooth
2. Verify that the scanner is Bluetooth Serial Port Profile
3. Verify that Bluetooth mode is to connect the scanner to match HID mode or SPP mode
4. When the scanner is in HID Bluetooth pairing mode connection, two blue lights will flash, Bluetooth scanner is in SPP mode counterpart connector when a blue light is blinking and the need to use the test tool in SPP

► Bluetooth scanners and mobile phone or computer has been connected, how paired with the phone or computer again?

1. Select the paired Bluetooth-enabled computer Bluetooth scanner panel, click on the "Delete" button
(Or cancel paired Bluetooth devices in the Bluetooth cell phone)
2. Set Bluetooth scanner, the scanner goes into pairing Bluetooth status (there are two ways)

(1) Open the Bluetooth scanner, press 8 seconds until the buzzer short beep twice Bluetooth indicator

(Blue) flashes quickly

(2) Scan the bar code "into pairing mode" indicator (blue) flashes quickly

3. Finally, follow the steps in front of the respective systems can operate

► Not automatically connect after re-plug the Bluetooth adapter or Bluetooth restart the phone how to do?

To ensure that no case of computer or mobile phone and other Bluetooth devices earlier, restart the scanner automatically connect Bluetooth

► Why SPP connection switching from mode to mode is not HID device?

Confirm whether the device is connected through the HID mode, such as the connection before, ignore the over-connected device name in the Bluetooth device search, re-pair connection

► How to Change More Scan Settings?

Please contact the manufacturer

Free declaration

Responsibility for beyond our scope of natural disasters (such as: earthquakes, floods, etc.) caused by losses, the company does not undertake any responsibility. In any case, for any loss associated with the use of this product and bring (in accordance with the instruction manual including loss resulting from the use of), such as: loss of profits, goodwill, business interruption, or loss / change the stored data, etc. and so any special, incidental, consequential or indirect losses caused by the company does not undertake any responsibility. Loss due to improper use of non-specified by the Company's communications hardware or software caused, the Company does not assume any responsibility.

For by using the message of the product obtained, data, files, or other products and services, the company does not provide any form of guarantee and technical support, and for these messages, data, files, or other products and services to users, do not assume any responsibility. For third-party software used in this product, the company does not undertake any form of guarantee and technical support responsibilities.

The contents of this manual in accordance with the "status quo" basis. Unless otherwise required by applicable law, the Company does not otherwise accuracy of this document, content and reliability make any kind, either express or implied warranty.